

STEERING SYSTEM

SECTION **ST**

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

CONTENTS

PRECAUTIONS AND PREPARATION	2	Installation.....	12
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER".....	2	Disassembly and Assembly.....	13
Precautions for Steering System.....	2	Inspection.....	14
Special Service Tools.....	3	POWER STEERING GEAR AND LINKAGE	15
Commercial Service Tools.....	4	Removal and Installation.....	15
NOISE, VIBRATION AND HARSHNESS (NVH)		Disassembly.....	18
TROUBLESHOOTING	5	Inspection.....	18
NVH Troubleshooting Chart.....	5	Assembly.....	20
ON-VEHICLE SERVICE	6	Adjustment.....	25
Checking Steering Wheel Play.....	6	POWER STEERING OIL PUMP	27
Checking Neutral Position on Steering Wheel.....	6	Pre-disassembly Inspection.....	27
Front Wheel Turning Angle.....	6	Disassembly.....	27
Checking Gear Housing Movement.....	7	Inspection.....	28
Adjusting Rack Retainer.....	7	Assembly.....	28
Checking and Adjusting Drive Belts (For power steering).....	7	TWIN ORIFICE POWER STEERING SYSTEM	30
Checking Fluid Level.....	7	Hydraulic Circuit.....	30
Checking Fluid Leakage.....	8	Wiring Diagram.....	31
Bleeding Hydraulic System.....	8	TWIN ORIFICE POWER STEERING SYSTEM - Trouble Diagnoses	33
Checking Steering Wheel Turning Force (For power steering).....	9	Precautions.....	33
Checking Hydraulic System.....	9	Diagnostic Procedure.....	34
STEERING WHEEL AND STEERING COLUMN	11	Control Unit Inspection Table.....	37
Removal.....	11	SERVICE DATA AND SPECIFICATIONS (SDS)	38
		General Specifications.....	38
		Inspection and Adjustment.....	38

Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

The Supplemental Restraint System “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a seat belt, help to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.

In addition to the supplemental air bag modules for a frontal collision, the supplemental side air bag used along with the seat belt helps to reduce the risk or severity of injury to the driver and front passenger in a side collision. The supplemental side air bag consists of air bag modules (located in the outer side of front seats), satellite sensor, diagnosis sensor unit (one of components of supplemental air bags for a frontal collision), wiring harness, warning lamp (one of components of supplemental air bags for a frontal collision). Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses (except “SEAT BELT PRE-TENSIONER” connector) can be identified with yellow harness connector (and with yellow harness protector or yellow insulation tape before the harness connectors).








Precautions for Steering System

- Before disassembly, thoroughly clean the outside of the unit.
- Disassembly should be done in a clean work area. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- Place disassembled parts in order, on a parts rack, for easier and proper assembly.
- Use nylon cloths or paper towels to clean the parts; common shop rags can leave lint that might interfere with their operation.
- Before inspection or reassembly, carefully clean all parts with a general purpose, non-flammable solvent.
- Before assembly, apply a coat of recommended Genuine Nissan PSF II or equivalent to hydraulic parts. Vaseline may be applied to O-rings and seals. Do not use any grease.
- Replace all gaskets, seals and O-rings. Avoid damaging O-rings, seals and gaskets during installation. Perform functional tests whenever designated.

PRECAUTIONS AND PREPARATION

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
KV48103404 (—) Torque adapter		Measuring pinion rotating torque
ST27180001 (J25726-A) Steering wheel puller		Removing steering wheel
ST29020001 (J24319-01) Pitman arm puller		Removing ball joint
KV48103500 (J26357 and J26357-10) Pressure gauge		Measuring oil pressure
KV48102500 (J33914) Pressure gauge adapter		Measuring oil pressure
ST3127S000 (See J25765-A) ① GG91030000 (J25765-A) Torque wrench ② HT62940000 (—) Socket adapter ③ HT62900000 (—) Socket adapter		Measuring turning torque
KV48104400 (—) Rack seal ring reformer		Reforming teflon ring

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT




HA

EL

IDX

PRECAUTIONS AND PREPARATION

Commercial Service Tools

Tool name	Description
Rear oil seal drift 	Installing rear oil seal NT063 a: 28 mm (1.10 in) dia.
Pinion oil seal drift 	Installing pinion oil seal NT063 a: 35 mm (1.38 in) dia.
Oil pump attachment 	Disassembling and assembling oil pump NT179 Unit: mm (in)

NVH Troubleshooting Chart

Use the chart below to help you find the cause of the symptom. If necessary, repair or re

Symptom	STEERING				Possible cause and ED PARTS	Reference page
	Noi	Shake	Vibration	Judder		
	X				Fluid level	ST-7
	X				Air in hydraulic system	ST-8
	X				Tie-rod ball joint swinging force	ST-19
	X				Tie-rod ball joint rotating torque	ST-19
	X				Tie-rod ball joint end play	ST-19
	X				Steering gear fluid leakage	ST-8
	X				Steering wheel play	ST-6
	X				Steering gear rack sliding force	ST-9
					Drive belt looseness	Refer to MA section.
			X	X	Improper steering wheel or damage	—
			X	X	Improper installation or looseness of tilt lock lever	ST-11
	X	X	X	X	Mounting rubber deterioration	ST-7
			X		Steering column deformation	ST-11
			X		Improper installation or looseness of steering column	ST-11
	X	X			Steering linkage looseness	ST-15
			X	X	PROPELLER SHAFT	Refer to PD section.
				X	DIFFERENTIAL	Refer to PD section.
	X	X	X	X	AXLE AND SUSPENSION	Refer to FA and RA sections.
	X	X	X	X	TIRES	Refer to FA section.
	X	X		X	ROAD WHEEL	Refer to FA section.
			X	X	DRIVE SHAFT	Refer to RA section.
	X	X		X	BRAKES	Refer to BR section.

X: Applicable

ST

BR

RA

FA

PD

AT

FE

EC

LG

EM

MA

GI

RS


BT

HA

EL

IDX

ON-VEHICLE SERVICE




Checking Steering Wheel Play

- With wheels in a straight-ahead position, check steering wheel play.

Steering wheel play:
35 mm (1.38 in) or less

- If it is not within specification, check the following for loose or worn components.

Steering gear assembly
Steering column
Front suspension and axle



Checking Neutral Position on Steering Wheel

Pre-checking


- Make sure that wheel alignment is correct.

Wheel alignment:
Refer to FA section, SDS.

- Verify that the steering gear is centered before removing the steering wheel.

Checking


1. Check that the steering wheel is in the neutral position when driving straight ahead.
2. If it is not in the neutral position, remove the steering wheel and reinstall it correctly.
3. If the neutral position is between two teeth, loosen tie-rods lock nuts. Turn the tie-rods by the same amount in opposite directions on both left and right sides.



Front Wheel Turning Angle

1. Rotate steering wheel all the way right and left; measure turning angle.


Turning angle of full turns:
Refer to FA section, SDS.



2. If it is not within specification, check rack stroke.

Rack stroke "S":
Refer to SDS (ST-38).

ON-VEHICLE SERVICE



Checking Gear Housing Movement

1. Check the movement of steering gear housing during stationary steering on a dry paved surface.
 - Apply a force of 49 N (5 kg, 11 lb) to steering wheel to check the gear housing movement.
Turn off ignition key while checking.


Movement of gear housing:
±2 mm (±0.08 in) or less

2. If movement exceeds the limit, replace mount insulator after confirming proper installation of gear housing clamps.

GI

MA

EM



Adjusting Rack Retainer

- Perform this driving test on a flat road.
1. Check whether vehicle moves in a straight line when steering wheel is released.
 2. Check whether steering wheel returns to neutral position when steering wheel is released from a slightly turned (approx. 20°) position.
- If any abnormality is found, correct it by resetting adjusting screw.

LC

EC

FE

AT

Checking and Adjusting Drive Belts (For power steering)


Refer to MA section, "Checking Drive Belts".

PD

FA

RA

BR



Checking Fluid Level

Check fluid level with dipstick on reservoir cap. Use "HOT" range at fluid temperatures from 50 to 80°C (122 to 176°F). Use "COLD" range at fluid temperatures from 0 to 30°C (32 to 86°F).

CAUTION:

- Do not overfill.
- Recommended fluid is Genuine Nissan PSF II or equivalent.

ST

RS


BT

HA

EL

IDX

ON-VEHICLE SERVICE



Checking Fluid Leakage

Check the lines for improper attachment and for leaks, cracks, damage, loose connections, chafing or deterioration.

1. Run engine at idle speed or 1,000 rpm.

Make sure temperature of fluid in oil tank rises to 60 to 80°C (140 to 176°F).

2. Turn steering wheel right-to-left several times.
3. Hold steering wheel at each "lock" position for five seconds and carefully check for fluid leakage.

CAUTION:

Do not hold the steering wheel in a locked position for more than 15 seconds.

4. If fluid leakage at connectors is noticed, loosen flare nut and then retighten.

Do not overtighten connector as this can damage O-ring, washer and connector.

5. If fluid leakage from power steering pump is noticed, check power steering pump. Refer to ST-27.
6. Check rack boots for accumulation of power steering fluid.

Bleeding Hydraulic System

1. Raise front end of vehicle until wheels clear ground.
 2. Add fluid into oil tank to specified level. Meanwhile, quickly turn steering wheel fully to right and left and lightly touch steering stoppers.
Repeat steering wheel operation until fluid level no longer decreases.
 3. Start engine.
Repeat step 2 above.
- Incomplete air bleeding will cause the following to occur. When this happens, bleed air again.
 - a. Generation of air bubbles in reservoir tank
 - b. Generation of clicking noise in oil pump
 - c. Excessive buzzing in oil pump

Fluid noise may occur in the valve or oil pump. This is common when the vehicle is stationary or while turning the steering wheel slowly. This does not affect performance or durability of the system.

以上内容仅为本文档的试下载部分，为可阅读页数的一半内容。如要下载或阅读全文，请访问：<https://d.book118.com/495231011000011212>