



WIRING DIAGRAM MAINUAL

CHAPTER 30 - ICE AND RAIN PROTECTION

CHAPTER LIST OF EFFECTIVE PAGES

<u>CHAPTER SECTION SUBJECT</u>	<u>PAGE</u>	<u>SHT</u>	<u>DATE</u>	<u>CHAPTER SECTION SUBJECT</u>	<u>PAGE</u>	<u>SHT</u>	<u>DATE</u>
R CHAPTER LIST OF EFFECTIVE PAGES	1		NOV 10/2003		2	1	AUG 12/2003
						2	AUG 12/2003
						3	AUG 12/2003
R CHAPTER TABLE OF CONTENTS	1		NOV 10/2003				
	2		AUG 12/2003				
CHAPTER ALPHABETICAL INDEX	1		JUN 08/1999				
30-11-11	1		AUG 09/2002				
	2		MAY 15/2003				
30-21-11	1		MAY 15/2003				
R 30-21-21	1		NOV 10/2003				
30-31-11	1		AUG 12/2003				
	2		AUG 12/2003				
30-31-12	1		MAY 15/2003				
30-41-11	1	1	MAY 15/2003				
		2	MAY 15/2003				
30-41-12	1	1	MAY 15/2003				
		2	MAY 15/2003				
30-42-11	1		JUN 05/2000				
	2		JUN 05/2000				
	3		MAY 15/2003				
30-71-11	1	1	AUG 12/2003				
		2	AUG 12/2003				
		3	AUG 12/2003				



WIRING DIAGRAM MANUAL

CHAPTER 30 - ICE AND RAIN PROTECTION

CHAPTER TABLE OF CONTENTS

<u>TITLE</u>	<u>CHAPTER SECTION SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>BOEING EFFECTIVITY</u>
<u>AIRFOIL</u>				
WING THERMAL ANTI-ICE SYSTEM	30-11-11	1	AUG 09/2002	YC941-YC948
		2	MAY 15/2003	YB581-YB599 YC949-YC970
<u>AIR INTAKES</u>				
ENGINE 1 NACELLE ANTI-ICE	30-21-11	1	MAY 15/2003	YB581-YB599 YC941-YC970
ENGINE 2 NACELLE ANTI-ICE	30-21-21	1	NOV 10/2003	YB581-YB599 YC941-YC970
<u>PITOT AND STATIC</u>				
PITOT AND PROBE HEATERS - SYSTEM A	30-31-11	1	AUG 12/2003	YB582-YB599 YC941-YC970
		2	AUG 12/2003	YB581-YB581
PITOT AND PROBE HEATERS - SYSTEM B	30-31-12	1	MAY 15/2003	YB581-YB599 YC941-YC970
<u>WINDOWS, WINDSHIELDS AND DOORS</u>				
WINDSHIELD HEAT SYSTEM - L. FRONT, R. SIDE AND L4 AND L5 WINDOWS	30-41-11 SHT 1 SHT 2	1	MAY 15/2003 MAY 15/2003	YB581-YB599 YC941-YC970



WIRING DIAGRAM MAINUAL

CHAPTER 30 - ICE AND RAIN PROTECTION

CHAPTER TABLE OF CONTENTS

<u>TITLE</u>	<u>CHAPTER SECTION SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>BOEING EFFECTIVITY</u>
WINDSHIELD HEAT SYSTEM - R. FRONT, L. SIDE AND R4 AND R5 WINDOWS	30-41-12 SHT 1 SHT 2	1	MAY 15/2003 MAY 15/2003	YB581-YB599 YC941-YC970
WINDSHIELD WIPERS	30-42-11	1	JUN 05/2000	YC941-YC945
		2	JUN 05/2000	YC946-YC947
		3	MAY 15/2003	YB581-YB599 YC948-YC970
<u>WATER LINES</u>				
DRAIN HEATERS	30-71-11 SHT 1 SHT 2 SHT 3	1	AUG 12/2003 AUG 12/2003 AUG 12/2003	YC941-YC970
		2		YB581-YB599
	SHT 1 SHT 2 SHT 3		AUG 12/2003 AUG 12/2003 AUG 12/2003	




WIRING DIAGRAM MANUAL

CHAPTER 30 - ICE AND RAIN PROTECTION

CHAPTER ALPHABETICAL INDEX

<u>TITLE</u>	CHAPTER SECTION <u>SUBJECT</u>	<u>TITLE</u>	CHAPTER SECTION <u>SUBJECT</u>
DRAIN HEATERS	30-71-11		
ENGINE 1 NACELLE ANTI-ICE	30-21-11		
ENGINE 2 NACELLE ANTI-ICE	30-21-21		
PITOT AND PROBE HEATERS - SYSTEM A	30-31-11		
PITOT AND PROBE HEATERS - SYSTEM B	30-31-12		
WINDSHIELD HEAT SYSTEM - L. FRONT, R. SIDE AND L4 AND L5 WINDOWS	30-41-11		
WINDSHIELD HEAT SYSTEM - R. FRONT, L. SIDE AND R4 AND R5 WINDOWS	30-41-12		
WINDSHIELD WIPERS	30-42-11		
WING THERMAL ANTI-ICE SYSTEM	30-11-11		

-E
4



YC941-YC948

WING THERMAL ANTI-ICE
SYSTEM

30-11-11

PAGE 1

AUG 09/2002

MANUAL NO: D280A124

30-11-11

PAGE 1

AUG 09/2002

以上内容仅为本文档的试下载部分，为可阅读页数的一半内容。如要下载或阅读全文，请访问：<https://d.book118.com/008046013060006024>