



Getting Started

Compaq Evo Notebook N620c Series

Document Part Number: 316625-001

January 2003

This guide explains how to set up your hardware and software, identify the exterior components of the notebook, find and install the latest versions of Compaq software, and find additional information and support.

© 2003 Compaq Information Technologies Group, L.P.

Compaq, the Compaq logo, Evo, ROMPaq, and SoftPaq are trademarks of Compaq Information Technologies Group, L.P. in the U.S. and/or other countries. Microsoft and Windows are trademarks of Microsoft Corporation in the U.S. and/or other countries. All other product names mentioned herein may be trademarks of their respective companies.

Compaq shall not be liable for technical or editorial errors or omissions contained herein or for the incidental or consequential damages in connection with the furnishing, performance, or use of this material. The information in this document is provided “as is” without warranty of any kind, and is subject to change without notice. The warranties for Compaq products are set forth in the express limited warranty statements accompanying such products. Nothing herein should be construed as constituting an additional warranty.

Getting Started

First Edition January 2003

Reference Number: N620c

Document Part Number: 316625-001

Contents

1 Hardware and Software Setup

Setting Up the Hardware	1-1
Setting Up the Software	1-4
Setting Up the Wireless MultiPort.	1-5
Installing Optional Applications	1-6
Notebook Support and Safety Tips	1-7
Confirming Hibernation Settings.	1-8

2 A Look at the Notebook

Display Components	2-1
Pointing Device Components	2-2
Pointing Stick Model	2-2
TouchPad Model	2-3
Dual Pointing Device Model	2-4
Top Components	2-5
Speakers and Memory Compartment	2-5
Lights	2-6
Buttons, Keys and Switches	2-8
Left Side Components	2-10
Right Side Components	2-11
Front Panel Components	2-12
Rear Panel Components	2-13
Bottom Components	2-15
Additional Standard Components	2-17

3 How to Get Information, Help and Updates

Using the Documentation Library CD	3-1
Viewing Guides on the CD	3-2
Contacting Technical Support	3-3
Updating Compaq Software	3-4
Obtaining the Compaq Support Software CD	3-5
Preparing to Update Software	3-5
Downloading Software from the Internet	3-6
Downloading System ROM.	3-7
Downloading Other SoftPaqs	3-8
Restoring Software.	3-9
Installing a Retail Version of an Operating System. . . .	3-10

Index

Hardware and Software Setup

Setting Up the Hardware




CAUTION: Setup must begin by connecting the notebook to AC power. To ensure that the correct drivers load and to prevent file corruption or damage to the components during initial setup:

- Do not set up the notebook while it is docked in an optional Port Replicator.
 - Do not remove the battery pack until the notebook has been connected to external AC power.
 - Do not run the notebook on battery power. Use external AC power throughout initial setup.
-


1. Place the notebook on a flat surface near an electrical outlet, then connect the notebook to external AC power.

Plug the AC adapter cable into the DC power connector ❶. Plug the power cord into the AC adapter ❷ and into an electrical outlet ❸. (Power cords and outlets vary by country.)




Connecting the notebook to external power

2. Open the notebook by sliding the display release latch to the right ❶ and raising the display ❷.



Opening the notebook

3. Turn on the notebook by sliding and releasing the power switch ❶.



Turning on the notebook

When the notebook is turned on:

- The power/standby light ❷ turns on.
- The battery pack in the battery bay begins to charge and the battery light ❸ turns on. The battery light remains on while the battery pack is charging and turns off when the battery pack is fully charged.

Setting Up the Software

The initial setup prompt is displayed on the screen as soon as the notebook is connected to external power.

Before responding to the initial setup prompt and proceeding through the online instructions, read the following setup information.



CAUTION: To ensure that the correct drivers load and to prevent file corruption or damage to the components during initial setup:

- Do not unplug the notebook from the electrical outlet.
 - Do not shut down the notebook.
 - Do not remove or insert a drive.
-
- After you begin the initial software setup, you must complete the entire process. Setup time varies depending on notebook configuration.
 - If you are prompted to select a language, choose carefully and keep in mind that the languages you do not choose will be deleted from the system and cannot be restored during initial setup.
 - During the setup process, you must accept the End User License Agreement to continue.

以上内容仅为本文档的试下载部分，为可阅读页数的一半内容。如要下载或阅读全文，请访问：<https://d.book118.com/228036000143006116>