



Hardware Reference Guide

HP t820 Flexible Thin Client

© Copyright 2013 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice.

Windows is a U.S. registered trademark of Microsoft Corporation.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

This document contains proprietary information that is protected by copyright. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Company.

Hardware Reference Guide

HP t820 Flexible Thin Client

First Edition: September 2013

Document part number: 730520–001

About this book

 **WARNING!** Text set off in this manner indicates that failure to follow directions could result in bodily harm or loss of life.

 **CAUTION:** Text set off in this manner indicates that failure to follow directions could result in damage to equipment or loss of information.

 **NOTE:** Text set off in this manner provides important supplemental information.

Table of contents

1 Product features	1
Standard configuration features	1
Front panel components	2
Rear panel components	3
Keyboard	4
Windows Logo Key	4
Serial number location	5
2 Hardware upgrades	6
Serviceability features	6
Warnings and cautions	6
Connecting the power cord	7
Removing the computer access panel	8
Replacing the computer access panel	9
Changing from desktop to tower configuration	10
Installing additional memory	11
SODIMMs	11
DDR3-SDRAM SODIMMs	11
Populating SODIMM sockets	12
Installing SODIMMs	13
Installing and removing a port cover	16
Installing a security lock	17
Cable lock	17
Padlock	18
HP business PC security lock	18
Front bezel security	22
Appendix A Battery replacement	24
Appendix B Electrostatic discharge	27
Preventing electrostatic damage	27

Grounding methods 27

Appendix C Computer operating guidelines, routine care and shipping preparation 28

 Computer operating guidelines and routine care 28

 Shipping preparation 29

Index 30

以上内容仅为本文档的试下载部分，为可阅读页数的一半内容。如要下载或阅读全文，请访问：<https://d.book118.com/268062124143006116>