



nivocompact FTC 731 Level Limit Switch

Installation and Operating Manual



Endress + Hauser

The Power of Know How



Contents	Page
Application	3
Application Examples	3
Technical Data	4
The Measuring System	6
Function	7
Installation	8
Project Planning	8
Examples for Mounting	9
Mounting	10
Type key	10
Connection	12
Wiring Connection	12
EC 30 (Two-Wire Connection) for AC	13
EC 32 (Three-Wire PNP) for DC	14
EC 33 (Three-Wire NPN) for DC	15
EC 34 (Relay Output) for DC and AC	16
Wiring On-Site	17
Calibration	18
Switching delay	18
Safety switching	19
Particular Cases: Capacitance Calibration	20
Function Control	22
Maintenance	22
Troubleshooting	22
Replacement of Parts	24
Returning Parts for Repair	24

以上内容仅为本文档的试下载部分，为可阅读页数的一半内容。如要下载或阅读全文，请访问：<https://d.book118.com/446225040100010142>