

Power Management

User Guide

© Copyright 2008 Hewlett-Packard
Development Company, L.P.

Windows is a U.S. registered trademark of
Microsoft Corporation.

The information contained herein is subject
to change without notice. The only
warranties for HP products and services are
set forth in the express warranty statements
accompanying such products and services.
Nothing herein should be construed as
constituting an additional warranty. HP shall
not be liable for technical or editorial errors
or omissions contained herein.

Second Edition: July 2008

Document Part Number: 490902-002

Product notice

This user guide describes features that are
common to most models. Some features
may not be available on your computer.

Table of contents

1 Power control and light locations

2 Shutting down the computer

3 Setting power options

Using power-saving states	4
Initiating and exiting Standby	4
Initiating and exiting Hibernation	5
Using the Power Meter	6
Using power schemes	7
Viewing the current scheme	7
Selecting a different power scheme	7
Customizing power schemes	7
Setting password protection upon exiting Standby	8

4 Using battery power

Finding battery information in Help and Support	10
Displaying the remaining battery charge	11
Inserting or removing the battery	12
Charging a battery	13
Managing low battery levels	14
Identifying low battery levels	14
Resolving a low battery level	15
Resolving a low battery level when external power is available	15
Resolving a low battery level when a charged battery is available	15
Resolving a low battery level when no power source is available	15
Resolving a low battery level when the computer cannot exit Hibernation	15
Calibrating a battery	16
Step 1: Fully charge the battery	16
Step 2: Disable Hibernation and Standby	16
Step 3: Discharge the battery	17
Step 4: Fully recharge the battery	18
Step 5: Reenable Hibernation and Standby	18
Conserving battery power	19

Storing a battery 20

Disposing of a used battery 21

5 Using external AC power


Connecting the AC adapter 23

Testing an AC adapter 24

Index 25

1 Power control and light locations

The following illustration and table identify and describe the power control and light locations.



Component	Description
(1) Power button	• When the computer is off, press the button to turn on the computer. • When the computer is on, press the button to shut down the computer. • When the computer is in Standby, press the button briefly to exit Standby. • When the computer is in Hibernation, press the button briefly to exit Hibernation. If the computer has stopped responding and Windows® shutdown procedures are ineffective, press and hold the power button for at least 5 seconds to turn off the computer. To learn more about your power settings, select Start > Control Panel > Performance and Maintenance > Power Options.

以上内容仅为本文档的试下载部分，为可阅读页数的一半内容。如要下载或阅读全文，请访问：<https://d.book118.com/558053133143006116>