

syngo X Workplace

AX

Upgrade Instructions

System

Hardware Upgrade

Also valid for:

LEONARDO AX

LEONARDO Workstation (AX, CT, MR)

syngo MM Workplace (AX, CT, IKM, MR, MI)

syngo X Workplace

X-Leonardo

© Siemens 2008

The reproduction, transmission or use of this document or its contents is not permitted without express written authority. Offenders will be liable for damages. All rights, including rights created by patent grant or registration of a utility model or design, are reserved.

Print No.: AX42-020.892.01.01.02

Replaces: n.a.

English

Doc. Gen. Date: 02.09

Document revision level

The document corresponds to the version/revision level effective at the time of system delivery. Revisions to hardcopy documentation are not automatically distributed.

Please contact your local Siemens office to order current revision levels.

Disclaimer

The installation and service of equipment described herein is to be performed by qualified personnel who are employed by Siemens or one of its affiliates or who are otherwise authorized by Siemens or one of its affiliates to provide such services.

Assemblers and other persons who are not employed by or otherwise directly affiliated with or authorized by Siemens or one of its affiliates are directed to contact one of the local offices of Siemens or one of its affiliates before attempting installation or service procedures.

1	General	4
	General Remarks	4
	Focus of the Document	4
	Terminology	4
	Requirements	4
	Contents of the Upgrade Kit	4
	Required Parts, Tools and Documents	4
	Required Documents	5
	Abbreviations	5
2	Workflow	6
	General	6
	Workflow with the syngo X Workplace	7
	Workflow with the syngo MM Workplace	8
	Compatibility List	9
	Return Checklist	10
	Service Key	11
3	Hardware / Software Upgrade	12
	Preliminary Works	12
	Hardware Upgrade	14
	General	14
	Upgrade of CELSIUS 670 to CELSIUS R640/650	14
	Upgrade of CELSIUS R610 to CELSIUS R640/650	15
	Upgrade of CELSIUS R630 to CELSIUS R640/650	16
	Software Upgrade	18
	Final Work Steps	19
	FORM A	20

General Remarks

Focus of the Document

Depending on the hardware installed on site, the CSE has to consider several issues during a hardware upgrade.

This document describes the necessary steps:

- ⇒ Backup and Restore of the Configuration Data.
- ⇒ Hardware replacement such as: Which board has to be reassembled in the new LEONARDO
- ⇒ Dongle replacement (if needed)
- ⇒ Logistic issues such as:
Report the new system in the IVK
Changes in the SRS Portal

This document should be viewed as a guideline. Not every work step (e.g. how to open the cover of the PC) is explained, but there are links to other documents that contain detailed instructions.

Terminology

What is referred to as LEONARDO in this document covers the syngo X Workplace as well as the syngo MM Workplace.

If there is a difference between the syngo X WP and syngo MM WP, it is explicitly stated.

Requirements

Installation and startup must be performed by technicians who have completed the LEONARDO training.

Contents of the Upgrade Kit

Depends on which kit was ordered.

- User Documentation
- Memory upgrade to 8 GB with InSpace 3D and SW version VB13 (syngo X WP) or VE30 A (syngo MM WP)
- CELSIUS R640/R650 (Level 2008) hardware

Required Parts, Tools and Documents

All tools, measurement equipment and auxiliary devices, with the exception of the “standard service and installation tools” are listed and specified in the auxiliary service tool catalog (**Service Tools Catalog**, see **SPC CD-ROM**).

- Service or installation tool kit

- Antistatic kit (TKD Static Dissipative Field Service Kit), 97 02 606 RE999
- Valid service key for the old LEONARDO.
A new Service Key is also required, depending on the SW version of the new LEONARDO. See ([Service Key / p. 11](#))

Required Documents

- Latest CB-DOC
For Service - Product Info - Network Solutions- Workplaces - syngo X WP
-----or-----
For Service - Product Info - Network Solutions- Workplaces - syngo MM WP

Abbreviations

IVK	I nstalled V olume C omponent D atabase
MNP	M anaged N ode P ackage
MM	M ulti M odality
SRS	S iemens R emote S ervice
SW	S oftware
WP	W orkplace

以上内容仅为本文档的试下载部分，为可阅读页数的一半内容。如要下载或阅读全文，请访问：<https://d.book118.com/615343304002011311>