

DeLaval milk meter MM27BC

Table of contents

EC Declaration of Conformity - DeLaval milk meter MM27BC	5
Safety precautions	7
1 Foreword.....	7
2 Disclaimer.....	7
3 Safety regulations.....	7
4 Warranty.....	8
General description	9
1 Features.....	9
2 Acronyms and abbreviations.....	10
Product data	11
1 Article number.....	11
2 Description.....	11
3 Accessories.....	12
3.1 VPR100.....	12
3.2 MM27BC fat sampler.....	12
3.3 Test probe.....	12
3.4 Milk inlet.....	12
3.5 Fixed air bleed.....	13
3.6 Protection plate.....	13
3.7 Service tool.....	13
4 Technical data.....	14
4.1 Wires.....	14
Function	15
1 Principle.....	15
2 Blood detection.....	16
3 Conductivity measuring.....	16
4 Regulator / shut-off.....	16
5 Air leakage detections.....	17
5.1 Block.....	18
5.2 Slip.....	18
5.3 Kick Off.....	18
6 ACR Stand Alone.....	19
Operators maintenance	21
1 General.....	21
2 Cleaning.....	21
2.1 Before Sampling.....	21
2.2 During Sampling.....	21
2.3 After sampling.....	22
2.4 Clean out of place = COP.....	23
3 Display messages.....	23
3.1 Following messages can be shown by commands during milking.....	23
3.2 Special display messages.....	24
3.3 Special messages if MM27BC is set to technician mode.....	25

DeLaval milk meter MM27BC

Table of contents

Troubleshooting..... 27

 1 Troubleshooting table..... 27



EC Declaration of Conformity

Name of product: **DeLaval milk meter MM27BC**

Report No. 80004450 v2

The product complies with requirements of the following directives:

Low voltage directive - 2006/95/EC

Electro magnetic compatibility directive - 2004/108/EC

Harmonised standards which have been used:

EN61000-6-4: 2007

EN61000-6-2: 2007

EN60950-1: 2001

Other technical standards and specifications used:

Tumba 2011-08-11

Signed:



Name: Andrew Turner

Position: Vice President

Department: BA Capital Goods

Contact: Olle Selander
P.O. Box 39
SE 147 21 TUMBA
Sweden

Name and address of manufacturer:

DeLaval International AB
P.O. Box 39
SE 147 21 TUMBA
Sweden

DeLaval milk meter MM27BC

Safety precautions

Safety precautions

Read this chapter carefully before you continue!

1 Foreword

It is your responsibility to see that any person involved with the use or operation of this equipment follows all safety and operational instructions. Under no circumstances should you allow this equipment to be used if the equipment is faulty or the operator does not completely understand the operation of the equipment.

2 Disclaimer

The information, instructions and parts listed are applicable and current on the date when issued. DeLaval reserves the right to make changes without notice.

3 Safety regulations



Mandatory!

Read the instructions carefully before using the equipment. Contact your local DeLaval dealer if there are parts of these instructions that you do not understand. Complying with the instructions ensure a correct and safe use of the equipment. Save the instructions for future use.



Caution!

Never clean the equipment with a high pressure cleaner or any other jet of water. The equipment is sensitive and can be destroyed by the high pressure.

DeLaval milk meter MM27BC

Safety precautions



Prohibited!

Never use solvents, detergents, solutions or alcohol on any part of the equipment. Failure to comply can destroy or harm the equipment.

4 Warranty

Note! DeLaval will not take any responsibility for damage resulting from faulty installation, operation or for improper or inadequate care and maintenance.

Note! DeLaval will not take any responsibility for any damage resulting from frost. The owner/user must take the necessary measurements to prevent the ambient temperature around the equipment from dropping to or below freezing point.

以上内容仅为本文档的试下载部分，为可阅读页数的一半内容。如要下载或阅读全文，请访问：<https://d.book118.com/586131225143010102>